

Tempo TreadTop Office Chair Instructions

INCLUDED PARTS



Base



Pneumatic Cylinder

Assembled Backrest and Seat



Armrests will arrive already installed

OPTIONAL PARTS



Foot Ring

STEP 1

ASSEMBLE BASE

Take the pneumatic cylinder from its protective carton and remove the protective washer that is taped to the narrow end, prior to assembly. Insert the wider end of the pneumatic cylinder into the center of the base.



STEP 2

OPTIONAL FOOT RING

If you purchased an optional foot ring, attach it now. Loosen the hand knob until the opening is wide enough to fit around the pneumatic cylinder. Attach the ring to the cylinder, such that the black crossbars are positioned below the chrome ring. Once you have the foot ring in your preferred position, turn the knob to secure it in place.



STEP 3

FINAL STEP

Insert the top end of the pneumatic cylinder into the bottom of the seat assembly.



iMovR Contact Information:

Phone: (888) 208-6770 or (425) 999-3550 • Fax: (425) 999-3550 • E-mail: customer@iMovR.com

Live Chat: www.iMovR.com • Hours: See iMovR.com/hours