




TRACKLESS Keyboard Tray

INSTALLATION INSTRUCTIONS

STEP 1

KEYBOARD TRAY PARTS

Make sure you have all the required parts and tools.



TOOLS (not included)



Allen wrench



Phillips head screwdriver



Power drill with drill bit



Adhesive Tape & Pen



Measuring Tape

STEP 2

DRILL PILOT HOLES IN TABLETOP

1. Measure to find the center of your desk (if that is where you want to locate your keyboard tray).
2. Fold the mounting template (included) 90° at the fold line. Align the fold line to the front edge of the work surface.
3. Tape the mounting template to the underside of the work surface.
4. OPTIONAL: Flip your desk up side down, on a soft surface, for an easier installation.
5. Drill six (6) 1/8" diameter x 1/2" deep pilot holes at the marked locations. Be careful not to drill through work surface.
6. Remove the template.



STEP 3

INSTALLATION INSTRUCTIONS

INSTALL KEYBOARD ARM

1. Install two (2) #12 x 3/4" wood screws into front two pilot holes, leaving a gap of 1/8" between the screw head and work surface.
2. Extend the keyboard tray by lifting the keyboard plate up, and pulling down and forward.
3. With the keyboard arm in the extended position, slide the two slotted holes on the arm mounting plate over the two screws. After the arm is in place, tighten the screws.
4. Install the four (4) remaining screws into the holes on the arm mounting plate

NOTE: If you have your desk upside down, you can turn it right side up now.



STEP 4

ATTACH THE KEYBOARD PLATFORM

Attach the keyboard platform to the arm using the four (4) machine screws, (4) lock washers, and (4) nuts. Tighten with a screwdriver as necessary.



ATTACH CLIP-ON MOUSE FENCE

Mouse fence snaps into place at your preferred location.



NOW YOUR TRACKLESS KEYBOARD TRAY IS READY TO USE!



NOTE: For the mouse platform version, you can unscrew the mouse platform and mount it to the left or right side of the keyboard platform.



USER INSTRUCTIONS

HOW TO USE YOUR TRACKLESS KEYBOARD TRAY

TILT

Keyboard Platform Tilt: Use knob to adjust the tilt of your keyboard tray, from -15° to $+10^{\circ}$.

Mouse platform tilt: Press up or down on the pad. Use an Allen key to adjust resistance.



HEIGHT

Trackless Keyboard Tray Height:

Lift the tray up from the front. The tray unlocks, allowing you to adjust position.



ROTATION

Trackless Keyboard Tray Rotation:

You can swivel the keyboard tray a full 360° around its mounting point.



POSITION

Mouse platform position: Press the gray circle to adjust the position of your mouse platform.

