# iMovR ZipLift

USER INSTRUCTIONS

HEIGHT ADJUSTMENT

STEP 1

ZIPLIFT+ 35", ZIPLIFT PATRIOT
Press and hold the levers.

**ZIPLIFT+ 42" HD, ZIPLIFT+ CORNER**
Press and hold lever on right side.

STEP 2

With two hands, lift up and out.*

With two hands, lift up and out.*

KEYBOARD TRAY ADJUSTMENT

Twist to loosen knob.

Lift tray to desired angle and tighten knob.

WEIGHT CAPACITY

## ZIPLIFT+ 35", ZIPLIFT+ CORNER, ZIPLIFT PATRIOT

A ≤ 35 lbs

B ≤ 5 lbs

A. The ZipLift+ 35", ZipLift+ Corner, and ZipLift Patriot hold up to 35 lbs. total.
B. The keyboard tray itself holds up to 5 lbs.

ZIPLIFT+ 42" HD

A ≤ 45 lbs

B ≤ 5 lbs

A. The ZipLift+ HD 42" holds up to 45 lbs. total.
B. The keyboard tray itself holds up to 5 lbs.

*Some heavier monitor setups may require more effort to lift. Lighter setups (such as laptop only) may require more effort to lower. When lowering the ZipLift, be sure to press both down and *forward*.

Visit iMovR.com for the widest selection of office fitness products!

iMovR