

The ENSIGN'S Adjustable Height Standing Desk




BEFORE YOU BEGIN

Congratulations on the purchase of The Ensign's Desk! Enjoy the health and productivity benefits that come from using an active workstation. The Ensign's Desk technological advancements allow it to arrive nearly fully-assembled so you can get standing in a matter of minutes.





ASSEMBLY INSTRUCTIONS





1. Connect Hand Controller Cable



2. Connect Power Supply Cable

CONNECT CABLES TO LEG 1

STEP 3



3. Connect Leg Motor Cable

PLACE CLAMP ON LEG 1 AND PRESS DOWN



STEP 5

PLACE LOCK IN CLAMP


Firmly press the Lock into place using your foot. When you hear a clicking sound, the Lock is secured.



STEP 8

ATTACH FOOT ONTO LEG 1

Place foot on leg. Align the four screwholes. Attach using the provided Hex Screws (4) and Allen Key.



STEP 7

PLACE LEG 2 INTO BASE

Note: Leg 2 has one cable socket for the Leg Motor Cable.

CONNECT LEG MOTOR CABLE TO LEG 2





REPEAT STEPS 4-6 FOR LEG 2



STEP 10



FLIP DESK

Two people for this step.

Note: Proceed carefully. When flipping the desk, do not roll it onto the edge with the controller or yank the feet too vigorously.



STEP 11



PLUG IN POWER SUPPLY & INITIALIZE YOUR DESK

- 1. Plug in power supply.
- 2. Hold down hand controller until desk lowers to its lowest limit. Release.
- 3. Hold paddle down for 5 seconds. Release.

PROGRAMMING YOUR CONTROLLER



DESK HEIGHT LIMITS

In case the desk cannot be operated in its entire span (e.g. a shelf is blocking the upwards movement or a filing cabinet is placed under the desk and blocking the downwards movement), it is possible to set an upper limit and a lower limit for the desk height.

Setting upper limit

- 1. Adjust desk to maximum allowable height.
- 2. Press "Bluetooth" and tilt controller up at the same time until light flashes.
- 3. Release "Bluetooth" and controller.

Setting lower limit

- 1. Adjust desk to minimum allowable height.
- 2. Press "Bluetooth" and press controller down at the same time until light flashes.
- 3. Release "Bluetooth" and controller.

The Ensign's intuitive hand controller is designed to help you seamlessly transition to a healthy and active work day.



Download the free mobile app!

For easy programming, advanced controller options, and instructions visit: *www.imovr.com/lander-app*



SET YOUR HEIGHT FAVORITES



Make moving between sitting and standing easy! Your Ensign's Desk can store up to two of your favorite height positions.

- 1. Raise or lower your desk to the height you want to save.
- 2. Press and hold the "Star" button for 2 seconds.
- Note: Make sure not to tilt the controller.
- 3. After the LED turns from blinking to static white, your height favorite is saved.

To erase all your height favorites, press and hold the "Star" button for 8 seconds.







RAISE OR LOWER YOUR DESK TO YOUR HEIGHT FAVORITES

- 1. Tilt and hold the controller in the direction you want to move.
- 2. When the desk stops, your height favorite is reached.

To raise or lower your desk beyond a height favorite, continue to tilt the controller until the desk moves again.

Enable Automatic Drive!

Reach a height favorite in just two taps of your controller. Download the mobile app and activate 'automatic drive' from the 'Settings' tab.

www.imovr.com/lander-app









MORE CONTROLLER OPTIONS

Initialization:

1. Lower desk to its lowest limit. Release paddle. Hold paddle down for 5 seconds. Release.

Factory Reset:

- 1. Press and hold the "Bell" and "Star" buttons together for 8 seconds.
- 2. When the controller flashes red 3 times, the factory reset is complete.
- 3. Once you have performed a Factory Reset, you **must** reinitialize your desk. (See initialization instructions above)

Switch to Metric (cm):

- 1. Press and hold the "Star" and "Bluetooth" buttons together for 5 seconds. The current measurement unit blinks.
- 2. Tilt the controller once to change units.
- 3. Press any button to confirm your choice.

SET YOUR REMINDERS TO STAND

Jumpstart your active routine with The Ensign's standing reminders. Your default reminder is set for 55 minutes of sitting. When the blinking LED turns from green to orange, it's time to stand!

Note: When you press the "Bell" button, the LED lights up white in three increasing intensities, each representing an interval.

- 1. Press the "Bell" button once to set the first interval (55 minutes).
- 2. Press the "Bell" button twice to set the second interval (50 minutes).
- 3. Press the "Bell" button three times to set the third interval (45 minutes).
- 4. Press the "Bell" button four times to turn reminders off. The LED will turn off.

Note: Make sure not to tilt the controller during these steps.

The reminder interval automatically restarts each time you adjust your desk to a sitting position.

Important: The controller does not remind you to sit, as you should do this whenever you feel your body needs to rest.

Customize Your Reminder Intervals & Get Push Notifications to Your Phone!

Download the mobile app for iOS or Android. Navigate to the 'You' tab to create custom reminder intervals and the 'Settings' tab to enable push notifications.



www.imovr.com/lander-app

Note: Make sure not to inadvertently tilt the controller during any of these functions.



Height Calibration:

- 1. If the leveling pads are fully open or you have caster wheels on your desk, the height displayed in the app may not match the true height of your desktop.
- 2. Press and hold the "Bell" and "Bluetooth" buttons together for 5 seconds.
- 3. Tilt the controller up or down until the in-app display shows the correct height measurement. (The desk will not move, only the display will change.)
- 4. Press any button to confirm your choice.

FINAL TOUCHES


LEVEL YOUR ENSIGN'S STANDING DESK

If your desk is on an uneven surface, adjust the leveling pads on the bottom of your desk's feet. Use a level on the tabletop to make sure the desk is perfectly even with the floor.

1. Twist the leveling pads counterclockwise to raise the desk height, or clockwise to lower.

2. Adjust each leveling pad until the tabletop is perfectly even with the floor.

By leveling your desk you can eliminate unwanted wobble from your workstation!



Preserve the Elegant Appearance of Your New Sit-Stand Desk with Comprehensive Cable Management

Tired of messy tangled wires exposed on and under your desk? iMovR Tucker professional cable management kits are designed to provide simple yet comprehensive solutions for any workstation configuration. Select from our pre-arranged kits or build your own system with our premium individual components.

The Tucker Basic Cable Management Kit is designed to be easily installed and comes standard with reusable and adjustable components to give you maximum flexibility and peace of mind. Every cable gets neatly routed together in a bundle under your desk and tracks down the back of the leg for a discreet and professional aesthetic.

The Tucker Advanced Cable Management Kit is for desks ranging from a simple setup to those with multiple routing needs, this kit bundles and guides all of your cables together to eliminate snagging and damage to equipment while providing under desk power and additional cable storage.

The Tucker[™] Pro Cable Management Kit for Adjustable Desks features a height-tracking link chain with a full array of mounting and routing essentials for device and cable protection, including a 6-outlet, under-desk surge protector and capacious cable tray.



ANTI-FATIGUE STANDING MATS

Stand comfortably for hours with Ecolast Standing Mats

Extra-thick, plush, and remarkably durable, EcoLast premium mats make standing time fly. Our wide assortment of sizes and colors can fit with any workspace and decor. And unlike cheaply-made department store comfort mats, EcoLast standing mats are firmer, provide more support, and can stand up to microbial and heat exposure.

Available at: www.imovr.com/standing-mats.html



MONITOR ARMS

Eliminate neck strain with an iMovR monitor arm

Highly adjustable with smooth movement, sleek looks, and high-grade componentry, iMovR's monitor arms are more than an ergonomic add-on, they're an integral part of your active workstation. Choose from light and heavy-duty single monitor arms, or a highly configurable dual monitor solution.

Available at: www.imovr.com/accessories/monitor-arms.html

ERGONOMIC KEYBOARD TRAYS

Improve your typing speed, comfort, and accuracy

Your Ensign's tabletop is pre-drilled for use with the iMovR Trackless Keyboard Tray. An essential part of an ergonomically-sound workstation, it offers up to 15 degrees of tilt for a strain-free typing experience. When you're not using it, simply stow it under your desk to free up space.

Available at: www.imovr.com/trackless-keyboard-tray.html

Want to learn more about our full line of products? Contact our workplace wellness specialists at sales@iMovR.com.





TROUBLESHOOTING

Symptom	Handling
Legs only move down and don't move up.	Initialize your desk (see instructions on p. 7 'More Controller Options'). Please contact your supplier.
Bluetooth app will not connect.	Re-download app. Restart mobile device. Ensure Bluetooth button on controller is activated.
One leg moves while the other does not.	Check the drive cable connection. Check to see if legs are perpendicular (at 90 degrees) to the desktop and the floor. If the legs are splayed inward or outward, the motor will not operate at an optimum level. Please contact your supplier.
The legs rise slowly.	Check to see if legs are perpendicular (at 90 degrees) to the desktop and the floor. If the legs are splayed inward or outward, the motor will not operate at an optimum level. Check that the weight load on the tabletop is not excessive.
Table slides down on its own.	Check that the weight load on the tabletop is not excessive. Please contact your supplier.

PREVENTATIVE MAINTENANCE, CLEANING, WARNINGS AND GOOD-SENSE TIPS

CLEANING THE BASE

Clean the base frame by wiping it down with a microfiber cloth moistened with a standard household cleaning solution. Never use solvents or abrasive or corrosive compounds on the frame. The base should be cleaned at regular intervals to remove dust and dirt. Inspect for mechanical damage; worn or broken parts should be replaced.

CLEANING THE DESKTOP

For routine cleaning, use warm, soapy water and a soft cloth. Afterwards, use another soft cloth to wipe the desktop dry immediately. Spills should be wiped up immediately. Do not allow puddles to form or sit on the desk. When necessary, use furniture cleaners designed specifically to clean or polish wood products. Avoid harsh chemicals and abrasive cleansers or pads. Always test any new furniture cleaner before using it on the entire desktop. Visit https://www. imovr.com/solid-wood-care for more details.

EXTENDED NON-USE

Unplug the power cord if you do not intend to use the desk for a long period of time.



WARNING

The components used are quite heavy and care should be exercised when lifting and moving the base and desk both during assembly and during use.

SPECIFICATIONS

Rated Lifting Capacity: 225 lbs. Height Range:

Single Stage: 27.35" - 47.5" including top, leveling feet fully closed, additional 0.5" height adjustment with leveling feet opened Dual Stage XT: 24" - 50" including top, leveling feet fully closed, additional 0.5" height adjustment with leveling feet opened; optional 6" height extenders available **Average Travel Speed:** 1.6" per second **Controller Type:** Bluetooth-enabled LED Touch Paddle **Special Features:** Anti-Collision Technology **Tabletop Construction:** MDF with Ergo-contoured 3D Lamination or Natual Solid Wood

Tabletop Thickness: .75"

Available Sizes:

Depth: 30" (3D Lamination) or 28" (Natural Solid Wood) Width: 41", 47", 53", 59", 65", 71"

Tabletop Finishes:

Natural Baltic Birch Antique Baltic Birch Toasted Cinnamon Baltic Birch Sunbleached Baltic Birch Gray Weathered Baltic birch Midnight Baltic Birch Black Cherry Baltic birch Wineberry Baltic Birch Espresso Baltic Birch

WARRANTY

iMovR warranty coverage includes a lifetime warranty on the steel frame, 10 years on the motors and electronics, and 5 years on the desktop.

THIS WARRANTY only covers defects as specified herein and does not include defects or damages attributable to improper installation, misuse or normal surface weathering, or defects or damages caused by accidents or fire or other casualty or Acts of God, or any other causes, or occurrences beyond the manufacturer's control. The exclusive remedial action provided for the customer hereunder shall be repair, restoration or replacement of the components as are found to be defective.

TABLE TOP: The replacement of new materials for those as may result in a color variance in comparison to the originally installed laminates due to slight color or texture changes by laminate manufacturers and is not indicative of a defect. IMovR reserves the right to substitute such laminates as are then being manufactured and is only obligated to match color and quality with such products as its manufacturing at the time of replacement.

ELECTRIC BASE FRAME: New base frames may have paint defects or scratches on components that are hidden beneath the surface of the desk, which are normal. Painted components that are normally visible to sitting or standing users after installation of the table top, that arrive in damaged condition, will be replaced under this warranty if iMovR is notified before the component is installed.

THIS WARRANTY is limited to repair, restoration and/or replacement by iMovR of any defective unit provided the manufacturer: (a) receives a written, faxed or e-mailed notice of claim under this warranty, including sufficiently high resolution photographs that clearly show the nature of the damage, and (b) within 30 days after notice of claim, is in receipt of the defective unit at its place of business, unless this requirement is waived by iMovR. The manufacturer will arrange for retrieval of the defective product via its carrier-of-choice. In some cases the manufacturer may elect not to retrieve the defective component, and may opt to send a replacement product based only on photographic evidence of warrantied defects. If upon receipt and inspection of the returned component it is determined that the damage was not due to a manufacturing flaw but rather one of the exempted reasons stated above, the costs of shipping the units to and from the manufacturer, plus the cost of the replacement component, shall be charged back to the customer.

LIMITATION OF LIABILITY: IT IS UNDERSTOOD AND AGREED THAT MANUFACTURER'S LIABILITY, WHETHER IN CONTRACT, IN TORT UNDER ANY WARRANTY, IN NEGLIGENCE OR OTHERWISE, SHALL NOT EXCEED THE RETURN OF THE AMOUNT OF PURCHASE PRICE FOR THE DEFECTIVE ITEM PAID BY PURCHASER AND UNDER NO CIRCUMSTANCES SHALL SELLER BE LIABLE FOR SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES. NO ACTION, REGARDLESS OF FORM, ARISING OUT OF THE TRANSACTIONS UNDER THIS AGREEMENT MAY BE BROUGHT BY THE PURCHASER MORE THAN ONE YEAR AFTER THE CAUSE OF THE ACTION HAS ACCRUED.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, AND SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS HEREIN MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY, FROM STATE TO STATE. THIS WARRANTY APPLIES ONLY IN THE U.S. AND CANADA. WARRANTIES OUTSIDE OF THE UNITED STATES MAY VARY. PLEASE CONTACT YOUR LOCAL DEALER FOR DETAILS.

TO OBTAIN warranty repair please contact the iMovR Customer Care Department with the contact information provided below.

IMovR Contact Information:

Phone: (888) 208-6770 or (425) 999-3550 Fax: (425) 999-3550 E-mail: customercare@iMovR.com Live Chat: www.iMovR.com Hours: See iMovR.com/hours